




















Harvest Kitchen & Mosaics







Cabinet Specifications

Updated July 2008

| | ITEM | WIDTH | HEIGHT | DEPTH | DESCRIPTION |
|---|-----------------------|-------|--------|-------|--|
|  | BASE CABINET : | | | | |
| | B9 | 9 | 34.5 | 24 | Single Door |
| | DB9 | 9 | 34.5 | 24 | Single Door (Spicie Rack only) |
|  | B12 | 12 | 34.5 | 24 | Single Door w/ Drawer |
| | B15 | 15 | 34.5 | 24 | Single Door w/ Drawer |
| | B18 | 18 | 34.5 | 24 | Single Door w/ Drawer |
| | B21 | 21 | 34.5 | 24 | Single Door w/ Drawer |
|  | B24 | 24 | 34.5 | 24 | Double Doors w/ Single Drawer |
| | B27 | 27 | 34.5 | 24 | Double Doors w/ Double Drawers |
| | B30 | 30 | 34.5 | 24 | Double Doors w/ Double Drawers |
| | B33 | 33 | 34.5 | 24 | Double Doors w/ Double Drawers |
| | B36 | 36 | 34.5 | 24 | Double Doors w/ Double Drawers |
| | B42 | 42 | 34.5 | 24 | Double Doors w/ Double Drawers (shaker only) |
|  | SINK BASE: | | | | |
| | SB24 | 24 | 34.5 | 24 | Sink Base (shaker only) |
| | SB27 | 27 | 34.5 | 24 | Sink Base (shaker only) |
| | SB30 | 30 | 34.5 | 24 | Sink Base |
| | SB33 | 33 | 34.5 | 24 | Sink Base |
| | SB36 | 36 | 34.5 | 24 | Sink Base |
| | SB42 | 42 | 34.5 | 24 | Sink Base |
|  | DRAWER BASE: | | | | |
| | 3DB15 | 15 | 34.5 | 24 | Three Drawers |
| | 3DB18 | 18 | 34.5 | 24 | Three Drawers |
| | 3DB21 | 21 | 34.5 | 24 | Three Drawers |
| | 3DB24 | 24 | 34.5 | 24 | Three Drawers |
|  | BASE SHELF: | | | | |
| | BEOS09 | 9 | 34.5 | 24 | End Shelf |
| | BEOS12 | 12 | 34.5 | 24 | End Shelf |

| | ITEM | WIDTH | HEIGHT | DEPTH | DESCRIPTION |
|---|----------------------|-------|--------|-------|--|
|  | BEOS12B | 12 | 34.5 | 12 | Two-Side End Shelf |
| BASE CORNER: | | | | | |
|  | BBC36 | 36 | 34.5 | 24 | Base Blind Corner (42" space required) |
|  | LSB36 | 36 | 34.5 | 36 | Lazy Susan Base Corner |
| | SBA36 | 36 | 34.5 | 36 | Sink Base Diagonal Corner |
|  | PANTRY: | | | | |
| | BRM1884 | 18 | 84 | 24 | Tall Pantry |
| | BRM3084 | 30 | 84 | 24 | Tall Pantry |
| | BRM1894 | 18 | 94 | 24 | Tall Pantry |
| | BRM3094 | 30 | 94 | 24 | Tall Pantry |
|  | OVEN CABINET: | | | | |
| | OVD3084 | 30 | 84 | 24 | Double Oven Cabinet |
| | OVD3094 | 30 | 94 | 24 | Double Oven Cabinet (Hole opening: 28.5"w x 53.5"h) |
|  | WINE RACK: | | | | |
| | WRC3018 | 30 | 18 | 12 | Lattice Wine Rack |
|  | BW0630 | 6 | 30 | 12 | Wine Rack |

| | ITEM | WIDTH | HEIGHT | DEPTH | DESCRIPTION |
|---|-----------------|-------|--------|---------------------|----------------------------------|
|  | W0930 | 9 | 30 | 12 | Single Door |
| | W1230 | 12 | 30 | 12 | Single Door |
| | W1530 | 15 | 30 | 12 | Single Door |
| | W1830 | 18 | 30 | 12 | Single Door |
| | W2130 | 21 | 30 | 12 | Single Door |
|  | W2430 | 24 | 30 | 12 | Double Doors |
| | W2730 | 27 | 30 | 12 | Double Doors |
| | W3030 | 30 | 30 | 12 | Double Doors |
| | W3330 | 33 | 30 | 12 | Double Doors |
| | W3630 | 36 | 30 | 12 | Double Doors |
|  | W0940 | 9 | 40 | 12 | Single Door |
| | W1240 | 12 | 40 | 12 | Single Door |
| | W1540 | 15 | 40 | 12 | Single Door |
| | W1840 | 18 | 40 | 12 | Single Door |
| | W2140 | 21 | 40 | 12 | Single Door |
|  | W2440 | 24 | 40 | 12 | Double Doors |
| | W2740 | 27 | 40 | 12 | Double Doors |
| | W3340 | 33 | 40 | 12 | Double Doors |
| | W3040 | 30 | 40 | 12 | Double Doors |
| | W3340 | 33 | 40 | 12 | Double Doors |
| | W3640 | 36 | 40 | 12 | Double Doors |
| | W4240 | 42 | 40 | 12 | Double Doors (Shaker Only) |
|  | Bridge Cabinet: | | | | |
| | W3012 | 30 | 12 | 12 | Single Lift-Up Door (glass door) |
| | W3612 | 36 | 12 | 12 | Single Lift-Up Door (glass door) |
|  | W3015 | 30 | 15 | 12 | Double Doors Bridge |
| | W3315 | 33 | 15 | 12 | Double Doors Bridge |
| | W3615 | 36 | 15 | 12 | Double Doors Bridge |
| | W3018 | 30 | 18 | 12 | Double Doors Bridge |
| | W3318 | 33 | 18 | 12 | Double Doors Bridge |
| | W3618 | 36 | 18 | 12 | Double Doors Bridge |
| | W3024 | 30 | 24 | 12 | Double Doors Bridge |
| | W3324 | 33 | 24 | 12 | Double Doors Bridge |
| W3624 | 36 | 24 | 12 | Double Doors Bridge | |

| | ITEM | WIDTH | HEIGHT | DEPTH | DESCRIPTION |
|---|----------------------------|-------|--------|-------|----------------------|
|  | Wall Corner: WBC2730 | 27 | 30 | 12 | Wall Blind Corner |
| | WBC2740 | 27 | 40 | 12 | Wall Blind Corner |
|  | WDC2430 | 24 | 30 | 24 | Wall Corner |
| | WDC2440 | 24 | 40 | 24 | Wall Corner |
|  | WDC2430B | 24 | 30 | 24 | Wall Diagonal Corner |
| | WDC2440B | 24 | 40 | 24 | Wall Diagonal Corner |
|  | Freg Top: W331824 | 33 | 18 | 24 | Refrigerator Top |
| | W361224 | 36 | 12 | 24 | Refrigerator Top |
| | W361524 | 36 | 15 | 24 | Refrigerator Top |
| | W361824 | 36 | 18 | 24 | Refrigerator Top |
| | W302424 | 30 | 24 | 24 | Refrigerator Top |
| | W332424 | 33 | 24 | 24 | Refrigerator Top |
| | W362424 | 36 | 24 | 24 | Refrigerator Top |
|  | Micro. Cabinet: MWC2730 | 27 | 30 | 12 | Microwave Cabinet |
| | MWC2740 | 27 | 40 | 12 | Microwave Cabinet |
|  | Wall Shelf: WEOS0930 | 9 | 30 | 12 | Wall Shelf |
| | WEOS1230 | 12 | 30 | 12 | Wall Shelf |
| | WEOS0940 | 9 | 40 | 12 | Wall Shelf |
| | WEOS1240 | 12 | 40 | 12 | Wall Shelf |

| ITEM | WIDTH | HEIGHT | DEPTH | DESCRIPTION |
|------------------------|-------|--------|-------|----------------------------|
| Misc Glass Door: | | | | |
| GCD1240 | 12 | 40 | 3/4 | Single Glass Door |
| GCD1540 | 15 | 40 | 3/4 | Single Glass Door |
| GCD1840 | 18 | 40 | 3/4 | Single Glass Door |
| GCD2140 | 21 | 40 | 3/4 | Single Glass Door |
| GCD13.540 | 13.5 | 40 | 3/4 | Double Glass Doors (W2740) |
| GCD16.540 | 16.5 | 40 | 3/4 | Double Glass Doors (W3340) |
| WDC2440BGCD | | 40 | 3/4 | Diagonal Glass Door |
| Solid Fillers: | | | | |
| FS340 | 3 | 40 | 3/4 | Solid Filler |
| FS640 | 6 | 40 | 3/4 | Solid Filler |
| FS396 | 3 | 96 | 3/4 | Solid Filler |
| End Panel: | | | | |
| PN24 X 34.5 | 24 | 34.5 | 3/4 | Dishwasher side panel |
| PN48 X 34.5 | 48 | 34.5 | 3/4 | finished plywood panel |
| PN24 X 96 | 24 | 96 | 3/4 | ref.side panel |
| PN48 X 96 | 48 | 96 | 1/4 | finished plywood panel |
| Crown Molding / TRIMS: | | | | |
| CM 8 X 2.5 | 96 | 2.5 | | crown molding |
| ACM 8 X 3.25 | 96 | 3.25 | | crown molding |
| BM8 | 96 | 3/4 | | accent trim |
| Trimming A | 3/4 | 96 | 1/4 | scribe molding |
| Trimming B | 3/4 | 96 | 3/4 | corner molding |
| Counter Support: | | | | |
| CTS8 x 10 | 8 | 10 | 1.5 | Wooden counter top support |
| Base Board: | | | | |
| TK8 x 5 mm | 96 | 4.5 | 1/4 | plywood toe kicks |
| Vanity Units | | | | |
| VA2421 | 24 | 31.5 | 21 | Double Doors / False Front |
| VA3021 | 30 | 31.5 | 21 | Double Doors / False Front |
| VA3621 | 36 | 31.5 | 21 | Double Doors / False Front |
| VDB12 X 21 | 12 | 31.5 | 21 | Three Drawers |
| VDB15 X 21 | 15 | 31.5 | 21 | Three Drawers |